

Hitachi Dynamic Link Manager (for Windows®) 8.1.0-00 Release Notes

About this document.....	1
Intended audience.....	1
Getting help	1
About this release	2
Product package contents.....	2
New features and important enhancements.....	2
System requirements.....	2
Resolved problems	7
Known problems	9
Installation precautions.....	10
Usage precautions.....	12
Documentation	19
Appendix A.....	19
Copyrights and licenses.....	40

About this document

This document (RN-00HS272-29, October 2014) provides late-breaking information about Hitachi Dynamic Link Manager (for Windows) 8.1.0-00. It includes information that was not available at the time the technical documentation for this product was published, as well as a list of known problems and solutions.

Intended audience

This document is intended for customers and Hitachi Data Systems partners who license and use Hitachi Dynamic Link Manager (for Windows).

Getting help

The Hitachi Data Systems Support Center staff is available 24 hours a day, seven days a week. To reach us, please visit the support website at <https://portal.hds.com> for current telephone numbers and other contact information. If you purchased this product from an authorized HDS reseller, contact that reseller for support.

About this release

This release is a major release that adds new features.

Product package contents

Medium	CD-ROM	Revision	Release Type	Prerequisite version of Service Pack
Software	Hitachi Dynamic Link Manager (for Windows)	8.1.0-00	Full Package	-
Documents	Hitachi Command Suite Dynamic Link Manager (for Windows®) User Guide	MK-92DLM129-31		

New features and important enhancements

[8.1.0-00 Additional Functions and Modifications]

(1) FCoE of VSP G1000 and XP7 are now supported.

System requirements

Refer to Chapter 3. Creating an HDLM Environment of the Hitachi Command Suite Dynamic Link Manager User Guide for Windows®.

Host

For details on supported Hosts, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - OSs Supported by HDLM

Supported OSs in a HAM environment are listed below:

Supported OS
Windows Server 2003(x86/x64/IPF)
Windows Server 2003 R2(x86/x64/IPF)
Windows Server 2008(x86/x64/IPF)
Windows Server 2008 R2(x64/IPF)

System requirements

Supported cluster software in a HAM environment is listed below:

OS	Service Pack	Cluster software
Windows Server 2008(x86/x64)	SP2	Microsoft Failover Cluster
Windows Server 2008 R2(x64/IPF)	No service pack / SP1	Microsoft Failover Cluster

Host Bus Adapter (HBA)

For information on supported HBAs and drivers, refer to Appendix A - Host Bus Adapter (HBA) Support Matrix.

Storage

For details on supported storage, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Storage Systems Supported by HDLM

When the Dynamic I/O Path Control function is enabled on Hitachi AMS 2000 series, use a microprogram version 08B8/D or later.

Requirements to use a HAM environment are as follows:

- HDLM supports the HAM functionality of the following storage system:
 - Hitachi Universal Storage Platform V/VM
 - Hitachi Virtual Storage Platform
 - HP XP24000/XP20000
 - HP P9500
 - HUS VM

The required microprogram versions are listed below:

Storage system	Interface	Microprogram version	Remark
Universal Storage Platform V/VM	FC I/F	60-06-10-XX/XX or later	X: voluntary number
		60-07-11-XX/XX or later (*1)	
Virtual Storage Platform	FC I/F	70-01-42-XX/XX or later	X: voluntary number
		70-03-00-XX/XX or later (*2)	
XP24000/XP20000	FC I/F	60-06-10-XX/XX or later	X: voluntary number
		60-07-11-XX/XX or later (*1)	

System requirements

P9500	FC I/F	70-01-42-XX/XX or later	X: voluntary number
		70-03-00-XX/XX or later (*2)	
HUS VM	FC I/F	73-03-0X-XX/XX or later	X: voluntary number

*1: If you use the HAM functionality with Microsoft Failover Cluster, apply 60-07-11-XX/XX or later.

*2: If you use the HAM functionality with USP V or XP24000, apply 70-03-00-XX/XX or later.

Operating Systems Requirements

For details on other supported operating systems, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - OSs Supported by HDLM

Prerequisite Programs

None.

Related Programs

For details on related programs, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Cluster Software Supported by HDLM
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Volume Managers Supported by HDLM

Supported Oracle RAC version:

OS	Version	DB File
Windows 2003 (x86) noSP	9.2.0.4.0	Raw
	10.1.0.2.0	ASM/ OCFS
	10.1.0.3.0	ASM/ OCFS
Windows 2003 (x86) SP1	10.1.0.4.0(*2)	ASM/ RAW
	10.2.0.1.0	ASM/ OCFS/ Raw
	10.2.0.2.0	Raw

System requirements

OS	Version	DB File
	10.2.0.3.0	ASM
	11.1.0.6.0	ASM/ OCFS/ Raw
Windows 2003 (x86) SP2	10.1.0.5.0(*1)	Raw
	10.2.0.2.0	Raw
	10.2.0.3.0	ASM
	11.1.0.6.0	ASM/ OCFS/ Raw
	11.1.0.7.0	Raw
Windows 2003 (IPF) SP1	10.1.0.4.0(*5)	Raw
	10.1.0.5.0(*1)	Raw
	10.2.0.3.0(*3)	ASM/ OCFS/ Raw
Windows 2003 (IPF) SP2	10.2.0.3.0(*3)	ASM/ Raw
Windows 2003 (x64)	10.2.0.4.0	ASM
Windows 2003 (x64) SP2	10.2.0.4.0	ASM/ Raw
	11.1.0.6.0	ASM/ OCFS/ Raw
Windows 2003 (x86) R2	10.2.0.2.0(*4)	OCFS/ Raw
	10.2.0.3.0(*2)	ASM
	10.2.0.4.0	ASM/ OCFS /Raw
	11.1.0.6.0	ASM/ OCFS/ Raw
Windows 2003 (x86) R2 SP2	9.2.0.7.0	Raw
	9.2.0.8.0	Raw
	10.1.0.5.0(*1)	ASM
	10.2.0.2.0(*4)	OCFS/ Raw
	10.2.0.3.0(*2)	ASM/ Raw

System requirements

OS	Version	DB File
	10.2.0.4.0	ASM/ OCFS/ Raw
	11.1.0.6.0	ASM/ OCFS/ Raw
	11.1.0.7.0	ASM
Windows 2003 (x64) R2	10.2.0.2.0	ASM
	10.2.0.3.0(*2)	ASM
	11.1.0.6.0	ASM/ OCFS/ Raw
Windows 2003 (x64) R2 SP2	10.2.0.2.0	ASM
	10.2.0.3.0	ASM
	10.2.0.4.0	ASM/ OCFS/ Raw
	11.1.0.6.0	ASM/ OCFS/ Raw
	11.1.0.7.0	ASM/ Raw
	11.2.0.3.0(*6)	ASM/ Raw
Windows 2008 (x86) noSP	10.2.0.4.0	ASM/ OCFS/ Raw
	11.2.0.3	ASM
Windows 2008 (x86) SP2	11.1.0.7.0	ASM/ Raw
	11.2.0.3(*6)	ASM
Windows 2008 (x64) noSP	10.2.0.4.0	ASM/ OCFS/ Raw
	11.1.0.7.0	ASM/ Raw
	11.2.0.4(*6)	ASM
Windows 2008 (x64) SP2	11.1.0.7.0	ASM
	11.2.0.1.0	ASM/ OCFS
	11.2.0.3.0(*6)	ASM
	11.2.0.4(*6)	ASM

Resolved problems

OS	Version	DB File
Windows 2008 (x64) R2 noSP	10.2.0.5.0	Raw
	11.2.0.1.0	ASM
	11.2.0.2.0	ASM
Windows 2008 (x64) R2 SP1	10.2.0.2.0	ASM
	11.2.0.1.0	ASM
Windows 2012 (x64) noSP	11.2.0.4.0(*6)	ASM

*1: Apply patch 5 when using this version.

*2: Apply patch 6 when using this version.

*3: Apply patch 2 when using this version.

*4: Apply patch 15 when using this version.

*5: Apply patch 13 when using this version.

*6: It is recommended that you use external redundancy for ASM disk groups.
To use normal or high redundancy, contact the Oracle Corporation.

Note:

(1) A configuration where Oracle RAC is installed on OCFS to share Oracle is not supported.

Memory and Disk Space Requirements

For details on memory and disk space requirements, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements -
Memory and Disk Capacity Requirements

HDLM Supported Configurations

For details on the condition that HDLM can manage space requirements, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements -
Number of LUs and Paths That Are Supported in HDLM

Resolved problems

[8.1.0-00 Modifications]

(1) The following problem was corrected:

Resolved problems

If you specify the `-storage` or the `-lu` parameter for the `set -dpc` operation of the HDLM command (`dlnkmgr`), the functionality is enabled or disabled for each system not for each storage system or each LU.

[Conditions]

This symptom may occur if both of the following conditions are met:

1. One of the following storage systems is used:

Hitachi AMS2000 series

Hitachi SMS series

HUS100 series

2. Either of the following commands is executed for the storage system in 1. :

```
dlnkmgr set -dpc { on | off } -pathid AutoPATH_ID -storage
```

or,

```
dlnkmgr set -dpc { on | off } -pathid AutoPATH_ID -lu
```

[Case ID]

None.

(2) The following problem was corrected:

A kernel panic may occur when an I/O request is sent to HDLM devices if you dynamically delete paths for the path registered initially (*1) in paths when an I/O is sent to HDLM devices.

*1: The path ID which is output by executing the HDLM command (`dlnkmgr view -path`) on the same LU is the smallest number.

[Conditions]

This problem may occur if all of the following conditions both (a) and (b) are met.

(a) An I/O request is sent to HDLM devices.

(b) Any path is dynamically deleted by either one of the following two procedures.

- All paths connecting the LUs are released while a path deletion function is enabled by using the HDLM command (`dlnkmgr set -rmlu on`).
- The connection of the target paths for deleting dynamically is released. The HDLM command `dlnkmgr delete -path` is executed after the status of the target paths for deleting dynamically is changed to Offline by using "`dlnkmgr offline -pathid PATH_ID`".

[Case ID]

None.

Known problems

- (1) In Hitachi NSC55, Hitachi Universal Storage Platform, XP12000 and XP10000, LUN 0 to 1023 can be assigned, but the support range for HDLM is from 0 to 255. Therefore, HDLM cannot recognize LUs of 256 to 1023. Moreover, in Hitachi Virtual Storage Platform G1000, VSP, USP V/VM, XP7, P9500, XP24000/20000, and Hitachi Unified Storage VM, LUN 0 to 2047 can be assigned, but the support range for HDLM is from 0 to 255. Therefore, HDLM cannot recognize LUs of 256 to 2047.
- (2) The Emulex FC Port Driver cannot be used.
- (3) In Windows 2003(IPF and x64), Windows 2008(IPF and x64) and Windows 2012 environment, the output function of performance information using Windows performance monitor console is not supported.
- (4) HDLM does not support the Microsoft Cluster Service and Microsoft Failover Cluster in an environment where Veritas Storage Foundation 5.1 for Windows is used.
- (5) When executing the DLMgetras (utility for collecting error information), specify an output directory which contains only alphanumeric characters. If it contains characters other than an alphanumeric character, the collected information may be outputted to a wrong directory. And when changing the output directory of DLMgetras utility executed from the Windows Start menu, do not enclose the output directory name in double quotation marks (").
- (6) When HDLM performance information is outputted in counter log of Windows performance monitor, counter log file with binary format is not supported. If counter log file with binary format is created, the following phenomenon may occur.
 - (a) There are cases where counter "0" is displayed in counter list of HDLM object when counter log file created with binary format is specified as "Data source" and "Add counter" is done. This counter "0" cannot be specified as display item of performance information. Even if counter "0" is displayed, it does not affect performance information of instance and other counters obtained.
 - (b) There are cases where "Disk Write Bytes/Sec" of performance counter offered by HDLM is displayed after substitution by index numbers managed by Windows. At such times it is possible to confirm performance information of "Disk Write Bytes/Sec" by selecting these substituted index numbers as counter.
- (7) When HDLM performance information is outputted using system monitor, a value outputted at first record in the system monitor can be a value different from the actual value. Further the same phenomenon may occur when counter log with CSV format is specified. When it occurs, ignore the first record.
- (8) When the path exists that has an I/O count value or an I/O error count value is 231 (2147483648) or more, the value becomes a negative value. As a result, a path that includes a negative value will not be displayed correctly in the Path List view of the HDLM GUI. In this case, confirm that the correct value of the I/O count or the I/O error count by either of the following methods:

Installation precautions

- Display the path information by using the view operation of the HDLM command.
- Calculate the correct value by using the following formula:

$$m = 232 (4294967296) + n$$

m: The correct value of the I/O count or the I/O error count

n: The negative value displayed in the Path List view of the HDLM GUI

- (9) When HDLM is installed on Windows 2008, the following event may be output to the application event log. However, it does not affect the system or HDLM operations.

```
Faulting application setup.exe_InstallShield, version
15.0.0.498, time stamp 0xNNNNNNNNNN, faulting module ole32.dll,
version N.N.NNNN.NNNNNNN, time stamp 0xNNNNNNNNNN, exception code
0xc0000005, fault offset 0xNNNNNNNNNN, process id 0xNNNN,
application start time 0xNNNNNNNNNNNNNNNNNNNN.
```

```
Log Name:      Application
Source:        Application Error
Event ID:      1000
Level:         Error
```

*1: N is a Number or Character.

Installation precautions

For details on HDLM installation, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Installing HDLM

Additional Precautions

- (1) If you removed HDLM 5.4, perform the following procedure to delete the HDLM driver setup information files from the system before restarting the host.
 1. Do a search for any setup information files (files with the inf file extension) that satisfy all of the following conditions:
 - The file is stored in the following folder:
Windows-installation-folder\inf
 - The file contains the text dlmfdrv.sys (a driver file).
 - The file has the name oemn.inf (where n is a number).
 2. Delete any setup information files that satisfy all of the above conditions. In addition, delete the files that have the same names as the above files, but with the extension pnf (oemn.pnf).

If you do not delete the correct files, the host might not run properly. Before deleting a file, make sure that it satisfies all of the above conditions.
- (2) When you remove HDLM 5.8.0 to 5.9.1, use the user account used to install HDLM. If HiCommand Device Manager (HDvM) Agent 5.0.0 to 5.8.0 was installed before HDLM 5.8.0 to 5.9.1 was installed, remove.

Updating installation of HDLM precautions

For details on updating HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Installing HDLM

Remove precautions

For details on HDLM remove, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Removing HDLM

Usage precautions

Precaution list at the time of the shift from HDLM 5.4 or before.

No	Items		Summary of precautions	Reference material
1	Applicable equipment	Management -target host	Supported OSs and prerequisite Service Packs and QFE have been changed.	<ul style="list-style-type: none"> - Manual Chapter 3. Creating an HDLM Environment - HDLM System Requirements - OSs Supported by HDLM - Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on HBAs and HBA Drivers
2		Host Bus Adapter	Supported HBAs and HBA drivers have been changed.	Appendix A Host Bus Adapter (HBA) Support Matrix
3		Storage System	Supported storage systems and support interfaces have been changed.	- Manual Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Storage Systems Supported by HDLM
4	Environment building	Preconditions	Emulex Corporation's FC Port Driver cannot be used.	7.2 Known Issue (2)
5		Storage System settings	You must not change vendor ID and product ID of the storage system. If you change these IDs, HDLM cannot recognize the storage system.	<ul style="list-style-type: none"> - Manual Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Storage Systems Supported by HDLM - Manual Chapter 4. HDLM Operation - Notes on Using HDLM - Using a Storage Management Program
6		Common notes on installation/update installation/remove	QFE838894 or later, or Service Pack 1 or later, must be installed when using the Windows 2003 Storport driver as the HBA driver.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on HBAs and HBA Drivers

Usage precautions

No	Items		Summary of precautions	Reference material
7			When installing or removing, make sure that there is one path per LU.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on New Installations and Upgrade Installations
8			A period of time exceeding 10 minutes may be required for installing or removing, depending on the environment.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on New Installations and Upgrade Installations - Manual Chapter 3. Creating an HDLM Environment - Removing HDLM
9		Precautions for installing	When HDLM is installed, the existing MPIO driver is overwritten by the MPIO driver that is supplied with HDLM. After confirming that this overwrite will not cause problems, perform the installation.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Related Software
10			An update installation cannot be used to update HDLM version 5.4 or earlier to version 5.5 or later.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on HDLM Versions
11			If a mirror volume of a Windows dynamic disk exists as an HDLM management target, close the management console of the disk.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on Windows

Usage precautions

No	Items		Summary of precautions	Reference material
12			If HDLM version 5.5 or later is installed in an environment in which HDLM 5.4 or earlier is installed, then DLMAAlertDriver is displayed in Device Manager as a non-Plug and Play driver.	- Manual Chapter 3. Creating an HDLM Environment - Installing HDLM - Migrating from HDLM 5.4 or Earlier to HDLM 5.5 or Later
13			If HDLM version 5.5 or later is installed, a specific error message is output to the event log.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on HDLM Versions
14			When an installation or update installation of HDLM 5.5 or later is executed, after rebooting, make sure that HDLM 5.5 or later is installed correctly and configure a multipath environment.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on New Installations and Upgrade Installations
15		Precautions for removing	hntr2t.dll is not deleted after removing HDLM in Windows 2003 (x86).	- Manual Chapter 3. Creating an HDLM Environment - Removing Hitachi Network Objectplaza Trace Library (HNTRLib2)
16			Even if HDLM is removed, some specific files might remain undeleted until the machine is restarted.	- Manual Chapter 3. Creating an HDLM Environment - Removing HDLM

Usage precautions

No	Items		Summary of precautions	Reference material
17		Other Precautions	Changes have been made with respect to the LU count that HDLM supports, as well as the path count per LU and the total path count.	- Manual Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Number of LUs and Paths That Are Supported in HDLM
18			Precautions for when using IDR function of VERITAS Backup Exec or VERITAS NetBackup have been changed.	- Manual Chapter 4.HDLM Operation - Notes on Using HDLM - Using Symantec Backup Exec for Windows and the Veritas NetBackup Intelligent Disaster Recovery Function
19	Function	Path status	Changes have been made with respect to the status transitions for path statuses.	Manual Appendixes A Functional Differences Between Versions of HDLM
20			Specification changes have been made for the function for dynamic LU deletion.	Manual Appendixes A Functional Differences Between Versions of HDLM
21		Changed operations on Windows	Changes have been made with respect to the drive letter display in Windows for LUs for which all paths result in errors.	Manual Appendixes A Functional Differences Between Versions of HDLM
22			Changes may have been made with disk number that Windows manage.	- Manual Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment - Notes on Migration or Upgrade Installation

Notes on compatibility between versions of HDLM

For details on compatibility between versions of HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Appendixes A Functional Differences Between Versions of HDLM

Notes on Environment Settings

For details on usage precautions when setting HDLM environment, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - HDLM System Requirements - Number of LUs and Paths That Are Supported in HDLM
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Notes on Creating an HDLM Environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Setting Up HDLM

Notes on General procedures

For details on usage precautions when using HDLM, refer to the following manual:

- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 2. HDLM Functions - Path Status Transition - Status Transitions of a Path
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 2. HDLM Functions - Monitoring Intermittent Errors - Intermittent Error Monitoring Actions
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 3. Creating an HDLM Environment - Clearing the Persistent Reservation
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 4. HDLM Operation - Notes on using HDLM
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 4. HDLM Operation - HDLM Operations Using the HDLM GUI - Notes on using the HDLM GUI
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 4. HDLM Operation - Using Commands for HDLM Operations - Notes on Using Commands
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 4. HDLM Operation - Reconfiguring the HDLM Operating Environment
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 5. Troubleshooting - Checking Error Information in Messages
- Hitachi Command Suite Dynamic Link Manager User Guide for Windows®
Chapter 6. Command Reference - view (Displays Information)
- Hitachi Command Suite Dynamic Link Manager GUI Help Section 3.1 HDLM operations using the HDLM GUI
- Hitachi Command Suite Dynamic Link Manager GUI Help Section 5.2 Path Management window

Additional Usage Precautions

- (1) Version numbers are displayed as follows after this version of HDLM is installed.

Function	Item	Version number
HDLM command (<code>dlnkmgr</code>)	HDLM Version	8.1.0-00
	Service Pack Version	Blank
	HDLM Manager	8.1.0-00
	HDLM Alert Driver	8.1.0-00
	HDLM Driver	8.1.0-00
HDLM GUI	HDLM version	8.1.0-00
Registry(*1)	TechnicalVersion	8.1.0-00

*1: Version numbers are stored in the following registry key.

[Key]

- When using Windows 2003(x86) or Windows 2008(x86)

HKEY_LOCAL_MACHINE\SOFTWARE\HITACHI\DynamicLinkManager

- When using Windows 2003(IPF/x64), Windows 2008(IPF/x64) or Windows 2012

HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\HITACHI\

DynamicLinkManager

Notes on HAM functionality support

- (1) In the case of displaying the LU information, the HAM information is not output by specifying the `all` parameter-value for the HDLM command. Specify the `ha` and `hastat` parameter-value instead.

(2) An online operation is performed on an owner path, a non-owner path's status may change to Offline(E). After performing an online operation on an owner path, use the HDLM command to make sure that the non-owner path's status is Online. If the non-owner path's status is Offline(E), change the status of HAM pairs to PAIR, and then perform an online operation on the Offline(E) path again.

(3) When you set up a HAM pair to be managed by HDLM, make sure that the host recognizes paths to the MCU (Primary VOL) and RCU (Secondary VOL) after the HAM pair is created.

Execute the `dlnkmgr view -lu -item hastat` operation. If `ha` is not displayed in the `HaStat` column, then the corresponding LU is not recognized as being in a HAM configuration.

Usage precautions

If the host recognizes the paths to the MCU and RCU before the HAM pair is created, restart the host after the HAM pair is created.

(4) If you release a HAM pair to recover the system after a HAM volume failure, do not restart a host that is connected to the MCU and RCU while the HAM pair is released.

If you need to restart the host while the HAM pair is released, disconnect all paths to the MCU and RCU, restart the host, re-create the HAM pair, and then reconnect the paths.

If you restart a host that is connected to the MCU and RCU while the HAM pair is released, the RCU volume will be recognized as a volume other than the MCU volume. If this occurs, restart the host after the HAM pair is re-created.

Execute the `dlnkmgr view -lu -item hastat` operation, and then confirm that `ha` is displayed in the `HaStat` column.

(5) If you release a HAM pair to recover the system after a HAM volume failure, do not disconnect or reconnect paths to the RCU while the HAM pair is released.

If you reconnect paths to the RCU while the HAM pair is released, the RCU volume will be recognized as a volume other than the MCU volume. If this occurs, restart the host after the HAM pair is re-created.

(6) If all the non-owner paths to RCU fail when the status of the owner paths that are connected to MCU is Online(S), a large amount of the following event is output to the system event log.

Source: mpio

Type: Error

Event ID: 32

Description: HDLM Device-Specific Module failed to return a Path to `\Device\MPIODiskN`.

(*N* is a number.)

When the status of owner paths is Online(S), do not disconnect the non-owner paths which are connected to the RCU.

(7) When you configure a cluster in an HAM environment, all cluster nodes need to be connected to both the MCU and RCU.

If a path error occurs in a cluster node, do not restart the node before the problem is resolved and the paths recover from the error.

Documentation

Available documents

Document name	Document number	Issue date
Hitachi Command Suite Dynamic Link Manager (for Windows®) User Guide	MK-92DLM129-31	October, 2014

Appendix A

Host Bus Adapter (HBA) Support Matrix

Use the iSCSI I/F adapter or Fibre Channel I/F adapters listed below. If plural adapters are to be used, all of them must be same type. If it is using mixed types of HBA, that might cause a path switch problem.

(1) For Hitachi storage system (Windows 2003 (no service pack))

OS	HBA		Driver
Windows 2003 (x86)	Fibre Channel	Emulex (*1)	SCSI Miniport 5-5.00a10 SCSI Miniport 5.01a0 SCSI Miniport 5.10a10 SCSI Miniport 5.20a9 STOR Miniport 5-1.00a15 STOR Miniport 1.02a3 STOR Miniport 1.03a9 STOR Miniport 1.10a4 STOR Miniport 1.20a3 STOR Miniport 2.01a4 STOR Miniport 2.50.007
		QLogic	SCSI Miniport 9.0.1.10 SCSI Miniport 9.0.1.12 SCSI Miniport 9.1.0.11 STOR Miniport 9.0.2.16 STOR Miniport 9.1.0.15 STOR Miniport 9.1.0.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.3.16 STOR Miniport 9.1.4.15
		HP	SCSI Miniport 9.1.3.11 STOR Miniport 1.02a7 STOR Miniport 1.11a1
		IBM	STOR Miniport 9.1.0.16

Appendix A

OS	HBA		Driver
	iSCSI	Adaptec	1.2
		Microsoft (*2)	Microsoft Initiator 1.05a Microsoft Initiator 2.0 Microsoft Initiator 2.01 Microsoft Initiator 2.02
Windows 2003 (IPF)	Fibre Channel	Emulex (*1)	SCSI Miniport 5.00a10 SCSI Miniport 5.00a11 SCSI Miniport 5.10a10 STOR Miniport 1.00a15 STOR Miniport 1.01a9 STOR Miniport 1.02a3 STOR Miniport 1.10a4 STOR Miniport 1.20a3 STOR Miniport 1.30a6
		QLogic	SCSI Miniport 8.2.3.11 SCSI Miniport 9.0.1.10 SCSI Miniport 9.0.1.12 SCSI Miniport 9.1.2.11 STOR Miniport 9.1.2.19

(2) For Hitachi storage system (Windows 2003 SP1, Windows 2003 (x64) (no service pack) and Windows 2003 R2 (no service Pack))

OS	HBA		Driver
Windows 2003 SP1 (x86) / Windows 2003 R2 (x86)	Fibre Channel	Emulex (*1)	SCSI Miniport 5.10a9 SCSI Miniport 5.10a10 SCSI Miniport 5.20a8 SCSI Miniport 5.20a9 SCSI Miniport 5.30a2 STOR Miniport 1.10a4 STOR Miniport 1.10x1 STOR Miniport 1.11a0 STOR Miniport 1.11a1 STOR Miniport 1.11a3 STOR Miniport 1.20a3 STOR Miniport 1.20a7 STOR Miniport 1.30a6 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.33.008
		QLogic	SCSI Miniport 9.0.0.12 SCSI Miniport 9.0.1.12

Appendix A

OS	HBA		Driver
			SCSI Miniport 9.0.2.11 SCSI Miniport 9.1.0.11 SCSI Miniport 9.1.0.13 SCSI Miniport 9.1.2.11 SCSI Miniport 9.1.3.11 STOR Miniport 9.0.2.16 STOR Miniport 9.1.0.16 STOR Miniport 9.1.2.16 STOR Miniport 9.1.2.17 STOR Miniport 9.1.2.19 STOR Miniport 9.1.3.16 STOR Miniport 9.1.4.15 STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.19 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.26
		HP	SCSI Miniport 8.2.3.11 STOR Miniport 9.1.0.18 STOR Miniport 9.1.7.17 STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.26
		IBM	SCSI Miniport 9.0.1.93 SCSI Miniport 9.1.0.60 (*3) SCSI Miniport 9.1.2.14 STOR Miniport 9.1.0.15
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.0 Microsoft Initiator 2.01 Microsoft Initiator 2.02 Microsoft Initiator 2.05 Microsoft Initiator 2.07
		QLogic	STOR Miniport 2.1.0.8 STOR Miniport 2.1.2.5
Windows 2003 SP1 (IPF)	Fibre Channel	Emulex (*1)	SCSI Miniport 5.10a10 SCSI Miniport 5.20a8 SCSI Miniport 5.20a9 STOR Miniport 1.10a4 STOR Miniport 1.11a0 STOR Miniport 1.11a3 STOR Miniport 1.20a3 STOR Miniport 1.20a7

Appendix A

OS	HBA		Driver
			STOR Miniport 1.30a6 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4
		QLogic	SCSI Miniport 9.0.1.12 SCSI Miniport 9.1.2.11 STOR Miniport 9.0.2.16 STOR Miniport 9.1.2.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.4.15
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.05
Windows 2003 (x64) / Windows 2003 R2 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 1.10a4 STOR Miniport 1.11a0 STOR Miniport 1.11a1 STOR Miniport 1.11a3 STOR Miniport 1.10x1 STOR Miniport 1.20a3 STOR Miniport 1.20a7 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.33.008
		QLogic	STOR Miniport 9.0.2.16 SCSI Miniport 9.1.0.11 STOR Miniport 9.1.0.16 STOR Miniport 9.1.0.18 STOR Miniport 9.1.2.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.3.16 STOR Miniport 9.1.4.15 STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.17 STOR Miniport 9.1.8.19 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.26
		HP	STOR Miniport 1.10x1 STOR Miniport 1.11x1 STOR Miniport 9.1.3.18 STOR Miniport 9.1.7.17 STOR Miniport 9.1.7.18

Appendix A

OS	HBA		Driver
			STOR Miniport 9.1.8.17 STOR Miniport 9.1.9.26
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.05 Microsoft Initiator 2.07
	Fibre Channel over Ethernet	QLogic	STOR Miniport 2.1.4.19 STOR Miniport 9.1.8.26
		HP	STOR Miniport 2.33.008
	Infini Band	Xsigo Systems BHCA-DDR-PCIE-2P + VP780 (*4)	STOR Miniport 2.6.0.4

(3) For Hitachi storage system (Windows 2003 SP2 and Windows 2003 R2 SP2)

OS	HBA		Driver
Windows 2003 SP2 (x86) / Windows 2003 R2 SP2 (x86)	Fibre Channel	Emulex (*1)	SCSI Miniport 5.10a9 SCSI Miniport 5.10a10 SCSI Miniport 5.30a2 STOR Miniport 1.11a0 STOR Miniport 1.20a3 STOR Miniport 1.20a7 STOR Miniport 1.30a6 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.30.020 STOR Miniport 2.32.002 STOR Miniport 2.33.008 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.018
		QLogic	SCSI Miniport 9.1.0.11 SCSI Miniport 9.1.0.13 SCSI Miniport 9.1.3.11 SCSI Miniport 9.1.4.10 STOR Miniport 9.0.2.16 STOR Miniport 9.1.0.16 STOR Miniport 9.1.2.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.3.16

Appendix A

OS	HBA		Driver
			STOR Miniport 9.1.4.6 STOR Miniport 9.1.4.15 STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.19 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.35 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.49
		HP	STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 3.0.0.0 STOR Miniport 9.1.3.16 STOR Miniport 9.1.3.18 STOR Miniport 9.1.6.15 STOR Miniport 9.1.7.17 STOR Miniport 9.1.7.18 STOR Miniport 9.1.7.65 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.25 STOR Miniport 9.1.8.28 STOR Miniport 9.1.9.26
		IBM	STOR Miniport 2.70.018 STOR Miniport 9.1.2.17 STOR Miniport 9.1.7.18 STOR Miniport 9.1.7.55 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.35 STOR Miniport 9.1.9.25
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.1.0.0 STOR Miniport 2.2.0.0 STOR Miniport 2.3.0.0 STOR Miniport 3.0.0.0
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.05 Microsoft Initiator 2.07
	Fibre Channel over	Emulex	STOR Miniport 2.10a7 STOR Miniport 2.32.002 STOR Miniport 2.70.018

Appendix A

OS	HBA		Driver
	Ethernet	QLogic	STOR Miniport 2.1.4.19 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.15
		Brocade	STOR Miniport 2.2.0.0
Windows 2003 SP2 (IPF)	Fibre Channel	Emulex (*1)	STOR Miniport 1.20a3 STOR Miniport 1.20a7 STOR Miniport 1.30a6 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.20.006 STOR Miniport 2.33.008 STOR Miniport 2.50.007
		QLogic	STOR Miniport 9.1.0.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.4.15
		HP	STOR Miniport 9.1.0.16 STOR Miniport 9.1.7.17
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.05
Windows 2003 SP2 (x64) / Windows 2003 R2 SP2 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 1.20a3 STOR Miniport 1.20a7 STOR Miniport 1.30a9 STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.30.020 STOR Miniport 2.32.002 STOR Miniport 2.33.008 STOR Miniport 2.41.002 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.018
		QLogic	SCSI Miniport 9.1.0.11 STOR Miniport 9.1.0.16 STOR Miniport 9.1.0.18 STOR Miniport 9.1.2.16 STOR Miniport 9.1.2.19 STOR Miniport 9.1.3.16

Appendix A

OS	HBA		Driver
			STOR Miniport 9.1.3.18 STOR Miniport 9.1.4.15 STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.17 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.16 STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.19 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.1.0.0 STOR Miniport 2.2.0.0 STOR Miniport 2.3.0.0 STOR Miniport 3.0.0.0
		HP	STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 3.0.0.0 STOR Miniport 9.1.3.18 STOR Miniport 9.1.7.17 STOR Miniport 9.1.7.18 STOR Miniport 9.1.7.65 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.45
		IBM	STOR Miniport 2.70.018 STOR Miniport 9.1.7.55 STOR Miniport 9.1.8.25
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Microsoft Initiator 2.05 Microsoft Initiator 2.07
	Fibre Channel over Ethernet	Emulex	STOR Miniport 2.10a7 STOR Miniport 2.32.002 STOR Miniport 2.70.018
		QLogic	STOR Miniport 2.1.4.19 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.15

Appendix A

OS	HBA		Driver
		HP	STOR Miniport 2.33.008 STOR Miniport 2.50.007
		Brocade	STOR Miniport 2.2.0.0

(4) For Hitachi storage system (Windows 2008 (no service Pack))

OS	HBA		Driver	
Windows 2008 (x86)	Fibre Channel	Emulex (*1)	STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.03.20 STOR Miniport 2.32.002 STOR Miniport 2.33.008 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.74.014.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0	
		QLogic	Bundle STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.25 STOR Miniport 9.1.11.28	
		HP	STOR Miniport 2.74.014.001 STOR Miniport 9.1.7.17 STOR Miniport 9.1.8.27	
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.2.0.0	
		Hitachi Compute Blade	Bundle (*4)	
		iSCSI	Microsoft (*2)	Bundle
		Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0	
		QLogic	STOR Miniport 2.1.5.15	
		Fibre Channel over	Emulex	STOR Miniport 2.10a7 STOR Miniport 2.32.002 STOR Miniport 2.70.018

Appendix A

OS	HBA		Driver
	Ethernet		STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 2.1.4.19 STOR Miniport 9.1.7.18 STOR Miniport 9.1.9.15
		Brocade	STOR Miniport 2.2.0.0
Windows 2008 (IPF)	Fibre Channel	Emulex (*1)	STOR Miniport 2.00a12 STOR Miniport 2.10a7
		QLogic	Bundle STOR Miniport 9.1.8.16
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Bundle
		QLogic	STOR Miniport 2.1.5.15
Windows 2008 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 2.00a12 STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.32.002 STOR Miniport 2.33.008 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.014 STOR Miniport 2.70.018 STOR Miniport 2.72.012.001 STOR Miniport 2.74.014.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	Bundle STOR Miniport 9.1.7.16 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.16 STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.27 STOR Miniport 9.1.9.47 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.26 STOR Miniport 9.1.11.20
		HP	STOR Miniport 2.70.018 STOR Miniport 2.74.014.001

Appendix A

OS	HBA		Driver
			STOR Miniport 9.1.7.17 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.45 STOR Miniport 9.1.9.49 STOR Miniport 9.1.11.20
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.2.0.0
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Microsoft (*2)	Bundle
		Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
		QLogic	STOR Miniport 2.1.5.15
	Fibre Channel over Ethernet	Emulex	STOR Miniport 2.10a7 STOR Miniport 2.32.002 STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 2.1.4.19 STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.15
		HP	STOR Miniport 2.42.002 STOR Miniport 2.50.007 STOR Miniport 2.76.003.001
		Brocade	STOR Miniport 2.2.0.0
	Infini Band	Xsigo Systems BHCA-DDR-PCIE-2P + VP780 (*4)	STOR Miniport 2.6.0.4

(5) For Hitachi storage system (Windows 2008 SP2)

OS	HBA		Driver
Windows 2008 SP2 (x86)	Fibre Channel	Emulex (*1)	STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.30.020 STOR Miniport 2.32.002 STOR Miniport 2.33.008 STOR Miniport 2.41.002

Appendix A

OS	HBA		Driver	
			STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.74.014.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0	
		QLogic	STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.25 STOR Miniport 9.1.10.27 STOR Miniport 9.1.11.28	
		HP	STOR Miniport 2.74.014.001 STOR Miniport 9.1.8.27 STOR Miniport 9.1.8.28	
		IBM	STOR Miniport 9.1.7.55 STOR Miniport 9.1.9.25	
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.2.0.0	
		Hitachi Compute Blade	Bundled (*4)	
		iSCSI	Microsoft	Bundled
		Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0	
	Fibre Channel over Ethernet	Emulex	STOR Miniport 2.32.002 STOR Miniport 2.70.018 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0	
			QLogic	STOR Miniport 9.1.9.15
			Brocade	STOR Miniport 2.2.0.0
			Cisco	STOR Miniport 2.1.0.11
	Windows 2008 SP2 (IPF)	Fibre Channel	Emulex (*1)	STOR Miniport 2.10a7
QLogic			STOR Miniport 9.1.8.16	
Hitachi Compute Blade			Bundled (*4)	
	iSCSI	Microsoft	Bundled	
Windows 2008 SP2 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 2.01a4 STOR Miniport 2.10a7 STOR Miniport 2.20.006 STOR Miniport 2.30.020 STOR Miniport 2.32.002	

Appendix A

OS	HBA		Driver	
			STOR Miniport 2.33.008 STOR Miniport 2.41.002 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.014 STOR Miniport 2.70.018 STOR Miniport 2.72.012.001 STOR Miniport 2.74.014.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0	
		QLogic	STOR Miniport 9.1.7.18 STOR Miniport 9.1.8.16 STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.27 STOR Miniport 9.1.9.47 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.26 STOR Miniport 9.1.11.20	
		HP	STOR Miniport 2.70.018 STOR Miniport 2.74.014.001 STOR Miniport 9.1.7.17 STOR Miniport 9.1.8.19 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.49 STOR Miniport 9.1.11.20	
		IBM	STOR Miniport 9.1.7.55 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.49	
		Brocade	STOR Miniport 1.0.0-06 STOR Miniport 1.1.0.1 STOR Miniport 2.2.0.0	
		Hitachi Compute Blade	Bundle (*4)	
		iSCSI	Microsoft (*2)	Bundle
			Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
		Fibre	Emulex	STOR Miniport 2.32.002

Appendix A

OS	HBA		Driver
	Channel over Ethernet		STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.15
		HP	STOR Miniport 2.33.008 STOR Miniport 2.42.002 STOR Miniport 2.50.007 STOR Miniport 2.76.003.001
		Brocade	STOR Miniport 2.2.0.0
		Cisco	STOR Miniport 2.1.0.25

(6) For Hitachi storage system (Windows 2008 R2)

OS	HBA		Driver
Windows 2008 R2 (IPF)	Fibre Channel	Emulex (*1)	STOR Miniport 2.20.006
		HP	STOR Miniport 2.50.007
Windows 2008 R2 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 2.20.006 STOR Miniport 2.30.018 STOR Miniport 2.30.020 STOR Miniport 2.32.002 STOR Miniport 2.40.005 STOR Miniport 2.41.002 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.72.012.001 STOR Miniport 2.74.009.001 STOR Miniport 2.74.014.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.19 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.27 STOR Miniport 9.1.8.28 STOR Miniport 9.1.8.38 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.27 STOR Miniport 9.1.9.47 STOR Miniport 9.1.9.49

Appendix A

OS	HBA		Driver	
			STOR Miniport 9.1.10.26 STOR Miniport 9.1.10.27 STOR Miniport 9.1.10.28 STOR Miniport 9.1.11.20 STOR Miniport 9.1.11.24 STOR Miniport 9.1.11.26	
		HP	STOR Miniport 2.33.005 STOR Miniport 2.33.008 STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.70.019 STOR Miniport 2.74.014.001 STOR Miniport 9.1.8.17 STOR Miniport 9.1.8.25 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.45 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.27 STOR Miniport 9.1.11.20	
		IBM	STOR Miniport 9.1.7.55 STOR Miniport 9.1.8.25 STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.36 STOR Miniport 9.1.11.24	
		Brocade	STOR Miniport 2.1.0.0 STOR Miniport 2.2.0.0 STOR Miniport 3.0.0.0 STOR Miniport 3.1.0.0 STOR Miniport 3.1.0.1 STOR Miniport 3.2.0.0 STOR Miniport 3.2.4.0	
		Hitachi Compute Blade	Bundle (*4)	
		iSCSI	Microsoft (*2)	Bundle
			Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
			HP	STOR Miniport 4.1.334.0
		Fibre Channel over Ethernet	Emulex	STOR Miniport 2.32.002 STOR Miniport 2.41.002 STOR Miniport 2.42.002 STOR Miniport 2.50.007

Appendix A

OS	HBA		Driver
			STOR Miniport 2.70.018 STOR Miniport 2.70.019 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 9.1.8.26 STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.15
		IBM	STOR Miniport 9.1.8.26 STOR Miniport 9.1.9.36
		HP	STOR Miniport 2.42.002 STOR Miniport 2.50.007 STOR Miniport 2.70.019 STOR Miniport 2.74.009.001 STOR Miniport 2.76.003.001
		Brocade	STOR Miniport 2.2.0.0 STOR Miniport 2.3.0.2 STOR Miniport 3.0.0.0 STOR Miniport 3.2.4.0
		Cisco	STOR Miniport 9.1.8.27

(7) For Hitachi storage system (Windows 2008 R2 SP1)

OS	HBA		Driver
Windows 2008 R2 SP1 (IPF)	Fibre Channel	Emulex (*1)	STOR Miniport 2.20.006 STOR Miniport 2.40.005
Windows 2008 R2 SP1 (x64)	Fibre Channel	Emulex (*1)	STOR Miniport 2.20.006 STOR Miniport 2.30.018 STOR Miniport 2.30.020 STOR Miniport 2.32.002 STOR Miniport 2.40.005 STOR Miniport 2.41.002 STOR Miniport 2.41.003 STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.74.009.001 STOR Miniport 2.74.014.001 STOR Miniport 2.74.016.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 9.1.8.27 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.27

Appendix A

OS	HBA		Driver	
			STOR Miniport 9.1.9.47 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.26 STOR Miniport 9.1.10.27 STOR Miniport 9.1.10.28 STOR Miniport 9.1.11.20 STOR Miniport 9.1.11.24 STOR Miniport 9.1.11.26	
		HP	STOR Miniport 2.33.005 STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.70.019 STOR Miniport 2.74.009.001 STOR Miniport 2.74.014.001 STOR Miniport 3.0.0.0 STOR Miniport 9.1.8.28 STOR Miniport 9.1.9.26 STOR Miniport 9.1.9.45 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.26 STOR Miniport 9.1.10.27 STOR Miniport 9.1.11.20	
		IBM	STOR Miniport 2.70.018 STOR Miniport 9.1.9.25 STOR Miniport 9.1.9.27 STOR Miniport 9.1.9.49 STOR Miniport 9.1.10.26 STOR Miniport 9.1.11.24	
		Brocade	STOR Miniport 2.1.0.0 STOR Miniport 2.2.0.0 STOR Miniport 2.3.0.2 STOR Miniport 3.0.0.0 STOR Miniport 3.1.0.0 STOR Miniport 3.2.0.0 STOR Miniport 3.2.4.0	
		iSCSI	Emulex	STOR Miniport 4.1.334.0 STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
			HP	STOR Miniport 4.1.334.0
		Fibre Channel over	Emulex	STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.76.003.001

Appendix A

OS	HBA		Driver
	Ethernet		STOR Miniport 10.0.720.0
		HP	STOR Miniport 2.50.007 STOR Miniport 2.70.018 STOR Miniport 2.70.019 STOR Miniport 2.74.009.001 STOR Miniport 2.76.003.001
	Brocade	STOR Miniport 3.2.4.0	
	Cisco	STOR Miniport 2.1.0.11	
		STOR Miniport 2.1.0.17	
STOR Miniport 2.1.0.20			
STOR Miniport 2.1.0.25			
STOR Miniport 2.1.0.27			
STOR Miniport 9.1.8.27			

Appendix A

(8) For Hitachi storage system (Windows 2012 with no service Pack)

OS	HBA		Driver
Windows 2012(x64)	Fibre Channel	Emulex (*1)	Bundle STOR Miniport 2.72.012.001 STOR Miniport 2.72.205.004 STOR Miniport 2.74.009.001 STOR Miniport 2.74.014.001 STOR Miniport 2.74.016.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	Bundle STOR Miniport 9.1.9.205 STOR Miniport 9.1.10.26 STOR Miniport 9.1.10.27 STOR Miniport 9.1.11.20 STOR Miniport 9.1.11.24 STOR Miniport 9.1.11.26
		HP	STOR Miniport 2.74.009.001 STOR Miniport 9.1.10.27 STOR Miniport 9.1.11.20 STOR Miniport 9.1.11.24
		Brocade	Bundle STOR Miniport 3.0.2.21 STOR Miniport 3.1.0.1 STOR Miniport 3.2.4.0
		Hitachi Compute Blade	Bundle (*4)
		iSCSI	Microsoft (*2)
		Emulex	STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
	Fibre Channel over Ethernet	Emulex (*1)	Bundle STOR Miniport 2.72.012.001 STOR Miniport 2.72.205.004 STOR Miniport 2.74.014.001 STOR Miniport 10.0.720.0
		QLogic	STOR Miniport 9.1.10.15
		Brocade	STOR Miniport 3.2.4.0
		HP	STOR Miniport 2.74.014.001
		Cisco	STOR Miniport 2.3.0.12

Appendix A

(9) For Hitachi storage system (Windows 2012 R2 with no service Pack)

OS	HBA		Driver
Windows 2012 R2(x64)	Fibre Channel	Emulex (*1)	Bundle STOR Miniport 2.74.214 STOR Miniport 2.76.002.001 STOR Miniport 2.76.003.001 STOR Miniport 10.0.720.0
		QLogic	Bundle STOR Miniport 9.1.11.3 STOR Miniport 9.1.11.24
		Brocade	STOR Miniport 3.2.4.0
		HP	STOR Miniport 9.1.11.24
		Hitachi Compute Blade	Bundle (*4)
	iSCSI	Emulex	STOR Miniport 4.9.160.0 STOR Miniport 10.0.732.0
		QLogic	STOR Miniport 2.1.5.38
	Fibre Channel over Ethernet	QLogic	STOR Miniport 9.1.11.12
		Brocade	STOR Miniport 3.2.3.1 STOR Miniport 3.2.4.0
		Cisco	STOR Miniport 2.3.0.20 STOR Miniport 2.4.0.8

(10) For EMC DMX Series, EMC CX Series and HP EVA Series (Windows 2003 SP1 or later and Windows 2008)

Check to a storage vendor about connectable HBA and its driver.

Notes:

*1: The following tables show the values for Emulex Driver.

For Emulex SCSI Miniport driver:

Item	Sub Item	Emulex Default Setting	HDLM Setting (FC-AL)	HDLM Setting (Fabric)
Driver Parameters	Reset TPRLO	0	0	0
	Topology	2	0	1

For Emulex STOR Miniport driver:

Item	Sub Item	Emulex Default Setting	HDLM Setting (FC-AL)	HDLM Setting (Fabric)
Driver Parameters	Topology	2	0	1

Appendix A

*2: Network Interface Card in which Ethernet connection is possible is required.

*3: Delete the following registry when using HDLM.

```
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services\ql2300\Parameters\Device  
Value : DriverParameter  
Data  : buschange=0
```

*4: All drivers applied to Hitachi HBA cards for Hitachi Compute Blade are supported.

*5: OS version of VP780 is as follows:

OS version: XgOS 2.6.0 (2.6.22.10-xg-04)

Copyrights and licenses

© 2014 Hitachi, Ltd. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or stored in a database or retrieval system for any purpose without the express written permission of Hitachi, Ltd.

Hitachi, Ltd., reserves the right to make changes to this document at any time without notice and assumes no responsibility for its use. This document contains the most current information available at the time of publication. When new or revised information becomes available, this entire document will be updated and distributed to all registered users.

Some of the features described in this document might not be currently available. Refer to the most recent product announcement for information about feature and product availability, or contact Hitachi, Ltd., at <https://portal.hds.com>.

Notice: Hitachi, Ltd., products and services can be ordered only under the terms and conditions of the applicable Hitachi Data Systems Corporation agreements. The use of Hitachi, Ltd., products is governed by the terms of your agreements with Hitachi Data Systems Corporation.

Hitachi is a registered trademark of Hitachi, Ltd., in the United States and other countries. Hitachi Data Systems is a registered trademark and service mark of Hitachi, Ltd., in the United States and other countries.

Archivas, BlueArc, Essential NAS Platform, HiCommand, Hi-Track, ShadowImage, Tagmaserve, Tagmasoft, Tagmasolve, Tagmastore, TrueCopy, Universal Star Network, and Universal Storage Platform are registered trademarks of Hitachi Data Systems Corporation.

AIX, AS/400, DB2, Domino, DS8000, Enterprise Storage Server, ESCON, FICON, FlashCopy, IBM, Lotus, OS/390, RS6000, S/390, System z9, System z10, Tivoli, VM/ESA, z/OS, z9, zSeries, z/VM, z/VSE are registered trademarks and DS6000, MVS, and z10 are trademarks of International Business Machines Corporation.

Microsoft, and Hyper-V are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Oracle and Oracle9i are either registered trademarks or trademarks of Oracle and/or its affiliates.

Oracle and Oracle Database 10g are either registered trademarks or trademarks of Oracle and/or its affiliates.

Oracle and Oracle Database 11g are either registered trademarks or trademarks of Oracle and/or its affiliates.

Symantec and Backup Exec are trademarks or registered trademarks of Symantec Corporation or its affiliates in the U.S. and other countries.

Copyrights and licenses

Veritas, and Veritas Storage Foundation are trademarks or registered trademarks of Symantec Corporation or its affiliates in the U.S. and other countries.

Veritas Volume Manager is a trademark of Symantec Corporation. Veritas, Veritas logo are trademarks or registered trademarks of Symantec Corporation in the U.S. and other countries.

Windows is a registered trademark of Microsoft Corp. in the U.S. and other countries.

Windows Server is a registered trademark of Microsoft Corporation in the United States and/or other countries.

This product includes software developed by the JDOM Project (<http://www.jdom.org/>).

This product includes software developed by the Apache Software Foundation (<http://www.apache.org/>).

All other trademarks, service marks, and company names in this document or website are properties of their respective owners.

Microsoft product screen shots are reprinted with permission from Microsoft Corporation.